

**TABLE OF CONTENTS:**

SAFETY – EMERGENCY SHUT OFF PROVISION.....PAGE 2

SAFETY – ELECTRICAL SAFETY .....PAGE 2

SAFETY – KILN LOCATION SAFETY.....PAGE 3

SAFETY – KILN USE SAFETY .....PAGE 3

SAFETY – KILN MAINTENANCE SAFETY .....PAGE 4

WHAT YOU NEED TO KNOW BEFORE YOU BEGIN.....PAGE 5

KILN CONSTRUCTION FEATURES.....PAGE 5

CONTROL STYLES .....PAGE 6

KILN SET-UP .....PAGE 7

ELECTRICAL SERVICE SPECIFICATIONS ..... PAGE 8

PREPARING TO FIRE.....PAGE 9

FIRING PROCEDURE.....PAGE 10

RECORD KEEPING.....PAGE 11

KILN MAINTENANCE – BEFORE EACH FIRING.....PAGE 11

KILN MAINTENANCE – LID MAINTENANCE AND REPAIR.....PAGE 12

KILN MAINTENANCE – SIDE HEATING ELEMENT REPLACEMENT.....PAGE 13

KILN MAINTENANCE – LID HEATING ELEMENT REPLACEMENT .....PAGE 14

KILN MAINTENANCE – THERMOCOUPLE REPLACEMENT.....PAGE 15

KILN MAINTENANCE – SIDEWALL MAINTENANCE AND REPAIR.....PAGE 15

TROUBLESHOOTING..... PAGE 16

WARRANTY ..... PAGE 17

## SAFETY

Read and understand this installation and operating manual as well as the controls manual before operating your kiln. If you have any questions please contact Evenheat Kiln at 989-856-2281 or at evenheat-kiln.com.

Kilns are as safe as any other electrical appliance when used under normal and proper operating conditions. To create and maintain this safe environment observe all safety precautions.

### Warning Symbol Descriptions

Warning symbols are used throughout this manual. These symbols alert the operator to certain hazards and important information. Pictured below are symbols used along with a description of each.



The Exclamation Point alerts you to particular cautions, hazards and information.



The Lightning Bolt alerts you to specific information regarding the risk of electric shock. Electric shock may result in injury or death.



The Heat Waves alert you to specific information regarding the risk of burn injury.

### Emergency Shut Off Provision



The kilns power supply connection (plug/receptacle, breaker or disconnect) acts as the emergency electrical power shut off. Access to these devices should be unobstructed and safe at all times.

All electrical installations for direct wired models (those without a plug/receptacle connection) must include a power disconnect near the kiln and that is easily accessible and safe for emergency power shutoff.

### Electrical Safety



A licensed electrician should be used for all electrical installation and service. All applicable local, state and federal electrical codes must be followed.

Use correct voltage, wire size and fuse or breakers. Kiln electrical requirements are located on the kiln nameplate. Make sure all electrical connections are tight. Avoid using aluminum wire.

Always use the proper electrical receptacle. Never alter the kiln cordset or cordset plug. Alterations can be dangerous. Alterations will void any warranties along with nullifying any Listing Agency markings.



Evenheat recommends that a voltage check be performed before placing the kiln into service, ideally before actual purchase. The kilns operating voltage (printed on the kilns nameplate) must match the applied voltage (actual electrical service voltage). If it does not, do not install or operate the kiln as potential electrical and fire hazards exist. Contact Evenheat for guidance in such cases.

The kiln must be properly grounded.



Unplug or disconnect the kiln from the electrical service before accessing the chamber for servicing or vacuuming. Do not attempt to touch or replace the heating elements while the kiln is plugged in or connected to the electrical service. Electric shock may result in serious injury or death.

Never, ever use an extension cord to operate a kiln.

### Kiln Location Safety

The best location for the kiln is a concrete floor. If not available, the kiln must be placed on a minimum of 2" of masonry extending at least 12" beyond the outside perimeter of the kiln.



Do not place or use kiln on combustible surface.

Place only on the metal stand provided by Evenheat Kiln, Inc.

The surface on which the kiln is placed shall be capable of safely supporting the combined weight of the kiln, kiln load and any operating personnel.

Observe all building, fire and safety codes when installing the kiln.

Do not install the kiln closer than 12" (31cm) from combustible wall surface or object or 36" from any ceiling surface in all opened and closed positions.

Install in a covered, well ventilated area.

Never place the kiln in a small, enclosed area such as a closet, cabinet or very small room. The room in which the kiln is placed into service shall be capable of safely dissipating all heat produced by the kiln.

Do not place the kiln in any structure resembling a carport or screened in porch. Avoid areas that are subject to outdoors weather.

Never install a kiln outside. Avoid moisture.

It is the user's responsibility to be knowledgeable regarding any and all contaminants, produced by the ware during firing, and take steps to properly and legally contain and dispose of these contaminants.

It is the user's responsibility to provide ventilation capable of removing all gases, fumes and other airborne contaminants produced by the ware during firing safely from work the area and building structure.



Do not store flammable or combustible products near or in the same room the kiln such as gasoline, paint, aerosol cans, paper, curtains, plastics, etc. Better yet, store these items in another separate structure designed for this purpose.

Position the power supply cables, power supply conduit, controller cables, pyrometer thermocouple leads and other materials in such a way as not to create a tripping hazard around the kiln.

The area around the kiln should be free of obstructions that interfere with the proper and safe operation of the kiln.

Never place anything under or above the kiln for storage. Absolutely nothing should be propped against the kiln.

### Kiln Use Safety



The surface of the kiln is hot and burn injuries are possible. Keep all children and unsupervised personnel away. Always wear protective clothing, gloves and eyewear when operating and handling a hot kiln.



Use extreme care when accessing a functioning and/or hot kiln. Your kiln is equipped with a power interrupt switch assembly that is designed to remove electrical power from all heating elements when either the lid or chamber is opened. This power interrupt switch assembly is a mechanical devise and it can fail. Under no circumstances should you touch the heating elements with your body or any other devises like tools. Electrical shock may result in serious injury or death.



Use care when accessing or looking into a hot kiln, this includes looking through a cracked lid or peepholes. High heat escapes quickly and burn injury may result. When accessing or looking into a hot kiln, approach slowly and wear protective clothing and gloves designed to withstand high heat and eyewear capable of filtering Infrared and Ultraviolet light.

Protective clothing should be worn when operating the kiln and includes, but is not limited to, cotton clothing, heat resistant gloves and eyewear capable of filtering Infrared and Ultraviolet light.

Do not operate the kiln over the maximum temperature rating printed on the nameplate.

Never fire a kiln unattended beyond its anticipated firing time.

Never allow the power cord to touch the kiln. If the cord, plug or receptacle become damaged discontinue use and replace immediately.

Do not remove the heat resistant, fiberglass sleeve affixed to the power cable. This sleeve protects the power cable from heat directed from the firing chamber (Studio Pro Models).

Do not open the chamber with the lid in the open position (Studio Pro Models).

Do not open the lid with the chamber in the open position (Studio Pro Models).

If your kiln model is equipped with support and safety bars (hold open the lid and/or chamber) be sure that they are secured within the wireform catch before releasing the lid or chamber. The hardware used for these support and safety bars should be inspected periodically for damage and wear. If these devices are not operating properly discontinue kiln use until repair or adjustment is made.

It is recommended that a fire extinguisher, capable of dousing an electrical fire, be accessible in the event of fire. Smoke detectors within the kiln room are also recommended.

Keep the kiln lid and/or chamber closed when not in use.



It is the user's responsibility to have knowledge of the material intended to be fired. If you are unsure as to the safety of firing a particular material contact your materials supplier for guidance. If you remain unsure as to the safety of firing a particular material do not do it. Firing hazards include materials that explode or produce toxic gases. Finished ware hazards include materials containing lead. Materials containing lead should not be used for articles intended for food use.

Fire all ware according to the material manufacturer's instructions. Improper firing may result in damage to the kiln or ware.

Do not use the kiln to prepare food, heat a living space, dry clothes or ice laden articles or use as a storage devise. The kiln is designed for one purpose and one purpose only: the firing of glass materials.

All kiln models not equipped with an automatic shutoff devise (electronic control or kiln sitter) must not be allowed to exceed the rated operating temperature indicated on the kiln nametag. To prevent kiln from exceeding this maximum temperature disconnect it from the electrical power supply.

A kiln will remain very hot long after the firing is complete. All safety recommendations should be followed, even with the kiln unpowered, to avoid any burn injuries. Keep children and other unauthorized personnel away.

When firing is complete, and during periods of non-use, remove power from the kiln by unplugging or by throwing the disconnect or breakers to the OFF position.

#### **Kiln Maintenance Safety**



Disconnect electrical power from the kiln before performing any kiln maintenance. Failure to disconnect the electrical power supply may result in electrical shock which can cause serious injury or death.

Replace any worn, damaged or defective parts immediately with Evenheat Kiln replacement parts only. Discontinue use kiln until parts are replaced.



When vacuuming the kiln use only HEPA filters on the vacuum. Prolonged expose to brick dust and other refractory materials can cause lung injury.

Inspect all electrical service connections periodically for wear.

Periodically check chamber jacket clamps for tightness. Tighten as necessary.

## What You Need to Know Before You Begin

This manual is designed to provide you with kiln set up, operation and basic firing instructions. It is not a manual designed to instruct you how to fire glass. You would be well advised to seek formal instruction through alternate sources such as instructional books, classes and internet.

## Kiln Construction Features

### Firebrick

Premium insulating firebrick is used to make up the firing chamber, bottom and lid. The brick is light weight and fragile and must be handled carefully and not bumped with shelves or ware. The brick is porous (small air pockets and voids) and stores heat produced by the kilns heating elements.

The sidewall and lid are specially routed to retain the heating elements without the use of metal pins. This special routing prevents the elements from pulling, drooping or sagging. High temperatures cause expansion and contraction of the brick and may lead to hairline cracks. This normal and in no way will affect the quality or performance of the kiln.

### Heating Elements

The heating elements are coils of wire that produce heat inside the kiln. They are made from the highest quality, high temperature wire available. Life expectancy of the elements will depend upon the number of firings and firing temperatures. Glass firing temperatures are considered to be relatively low which helps extend life. Care should be taken that no foreign matter comes in contact with the elements. This includes glass, shelf primer or ether fired ware. Regular vacuuming of the element grooves is recommended.

### Jacket and Lid Bands

Most kiln models are jacketed in stainless steel. Stainless steel is chosen for its long life, corrosion resistance and strength. Some tarnishing may appear, particularly at higher temperatures. The integrity of the construction is not affected by this tarnishing and may be removed with stainless polish. It is recommended that the lid bands and chamber jacket bands (if visible) be tightened after each of the first three firings and checked for tightness periodically afterwards.

### Peepholes and Peephole Covers



Peepholes serve two purposes. The first is to allow moisture and gas to escape from the kiln during firing. The second is to allow the user to check the firing chamber during the firing process. Evenheat uses a special metal peephole cover that is permanently attached to the kiln. These covers will become hot during firing. Use protective gloves when opening and closing the peephole covers. Care should also be taken when viewing the chamber through the peephole. High heat escapes quickly and cause injury if viewed too quickly or closely. Use protective eyewear.

### Control Panel

The control panel contains all electrical and electronic components used to operate the kiln. This panel is separated from the kiln body by a heatshield. This shield lowers the temperatures seen at the components thereby extending the life of these components.

## Control Styles

### Automatic Controls



Automatic control allows you to precisely control all firing rates, temperatures and soak times. Simply program the firing data into the controller and start the firing. Temperatures soak times and other firing data are displayed via a digital display. These controls also have a host of other functions that makes firing more enjoyable.

Evenheat uses a variety of automatic temperature controls. Operation of these controls is beyond the scope of this manual. Your best opportunity to learn about your particular control is to read and understand the operations manual that was included with your kiln.



Scan this QR code to view instructional programming videos for both the Evenheat Set-Pro and Rampmaster controls.

You will also find these instructional videos and manuals on our web site [www.evenheat-kiln.com](http://www.evenheat-kiln.com)



### Infinite Switch



Depending on your model, your kiln will contain up to three of these switches. Each lid element is controlled by a single switch while all side elements are generally controlled by a single switch.

The infinite switch can best be described as a percentage switch. That is to say it supplies power for a period of time and removes power for a period of time. It repeats this cycle over and over. The “on” time verses the “off” time depends upon the setting of the switch.

When operating, the infinite switches will make a slight popping noise. This is normal.

### Pyrometer



A pyrometer is a meter used to measure the temperature in side the kiln. A thermocouple (sensing probe) is attached to the meter and is inserted 1-1/2” to 2” (4 to 5cm) into the kiln chamber.



## Kiln Set-up

### Firing Location

Consideration of many factors must be given when choosing a location for the kiln. Refer to the beginning of this manual for a list of precautions that must be followed. Use common sense. Crowded, close quarters should be avoided. Ventilation is a must. Give yourself room to work.

### Stand Assembly

If your kiln is 23" or larger in diameter, it is Dyna-Lift Ready. Please refer to Dyna-Lift Instructions to assemble your stand.

The kiln stand is shipped disassembled. Tools required for assembly includes a Phillips screwdriver and a 7/16" wrench.

Layout the frame angles in a square or rectangle on larger models with the bolt holes vertical. The corners of the frame angles are overlapped. Place the legs inside each corner and insert a bolt in each hole. Thread on nuts and tighten securely. Place plastic feet on the ends of each leg. Position the stand and check that it's level. Shim with metal if necessary.



### Placement of the Kiln

Center the kiln on the stand so that it's stable and allows for the minimum of 12" to the closest wall or object. The kiln may have a metal bottom which is secured with screws. Check that the kiln is level and shim with metal if necessary. Once positioned, check again that it's stable. Do so with the lid closed and again with the lid opened.

If your kiln is equipped with swing away peephole covers, loosen the screw ¼ turn to allow the cover to swing easily. The peephole covers are fastened securely for shipping.

The kiln should be vacuumed completely with a small dusting brush to remove any brick or brick dust generated during shipping. Be sure to vacuum the lid element groove. Dust in these grooves will cause imperfections in the finished piece. Be careful as brick is fragile.

## Electrical Service Specifications

### Connection



To operate safely and efficiently your kiln needs the proper electrical outlet with the correct amperage capacity and voltage. A licensed electrician or local power authority should determine if you have the proper service. All electrical changes should be performed by a licensed electrician.

Refer to the beginning of this manual for a list of precautions that must be followed. It is very important that all wire size and fusing/breaker selections are correct. Improper selection can lead to overheating of the cordset, receptacle, supply lines and fusing/breaker. Copper wire is preferred and we strongly suggest avoiding aluminum wire.

Through common sense and professional electrical service your kiln will provide many years of trouble free service.

Glass Kiln Electrical Specifications												
Model	Width	Length	Depth	Max. Temp	Cubic Feet	Volts	Amps	Watts	Fuse Size	Min. Wire Size	USA NEMA Config.	Ship Weight
Copper	10.0"	6.5"	9.0"	2200°F	.340 ft <sup>3</sup>	120V	12A	1440W	15A	12AWG	5-15R	54 lb.
Studio 8 Studio Pro	8.0"	8.0"	4.5"	1800°F	.367 ft <sup>3</sup>	120V	12A	1440W	15A	12AWG	5-15R	30 lb.
Fishbone	14.25"	3.5"	7.5"	1200°F	.22 ft <sup>3</sup>	120V	12A	1440W	15A	12AWG	5-15R	45 lb.
Hot Shot GT 14-6	14.5"	N/A	6.5"	1800°F	.700 ft <sup>3</sup>	120V	12A	1440W	15A	12AWG	5-15R	70 lb.
TKG GT 4050	19.75"	15.75"	6.5"	1650°F	1.17 ft <sup>3</sup>	240V	15A	3600W	20A	12AWG	6-20R	135 lb.
Studio Pro 14	14.5"	14.5"	6.5"	1650°F	.80 ft <sup>3</sup>	120V	15A	1800W	20A	12AWG	5-15R	130 lb.
Studio Pro 15	14.5"	14.5"	6.5"	1650°F	.80 ft <sup>3</sup>	120V	15A	1800W	20A	12AWG	5-15R	120 lb.
Studio Pro 17	17"	17"	6.5"	1650°F	1.1 ft <sup>3</sup>	120V	18A	2160W	20A	12AWG	5-20R	130 lb.
GTS 18-9	17.5"	N/A	9.0"	1800°F	1.30 ft <sup>3</sup>	240V	27A	6460W	40A	8AWG	6-30R	100 lb.
GTS 23-9	23.5"	N/A	9.0"	1800°F	2.34 ft <sup>3</sup>	240V	30A	7200W	40A	8AWG	6-50R	140 lb.
GTS 23-13	23.5"	N/A	13.5"	1800°F	3.51 ft <sup>3</sup>	240V	30A	7200W	40A	8AWG	6-50R	195 lb.
Studio Pro 24	24"	24"	13.5"	1800°F	4.20 ft <sup>3</sup>	240V	32A	7680W	40A	8AWG	6-50R	280 lb.
GTS 2541-9	41.0"	25.5"	9.0"	1800°F	4.80 ft <sup>3</sup>	240V	40A	9600W	50A	6AWG	6-50R	280 lb.
GTS 2541-13	41.0"	25.5"	13.5"	1800°F	7.20 ft <sup>3</sup>	240V	40A	9600W	50A	6AWG	6-50R	310 lb.
Studio Pro 41	40.5"	25.25"	13.5"	1800° F	7.52 ft <sup>3</sup>	240V	45A	10,800W	50A	6AWG	6-50R	365 lb.
Specifications subject to change without notice or obligation. Standard production models are 120V and 240V, single phase. Other voltage and phase configurations are available including 100V, 200V, 208V, and 380/400/415V.												

## Preparing to Fire

### Glass Preparation

For successful glass firing all glass being fused or otherwise combined must have the same expansion characteristics or COE. Attempting to kiln work glasses that do not share the same COE will result in breakage. This breakage occurs from stress that is created by COE differences.

It's important that your glass be clean. Fingerprints and oil from the cutter can fire into the surface of the glass and leave an unwanted film. You may use dish soap, commercial glass cleaner or isopropyl alcohol. Dry the glass with a soft towel. Handle with care.

### Kiln Wash

Kiln wash, a.k.a. shelf primer, is a protective coating used to prevent glass from sticking to the firing surface. All items used for firing from shelves to molds must be coated with this kiln wash. Kiln wash is normally supplied in a dry form and must be mixed with water before application.

Mix the kiln wash to desired consistency. Water to powder ratios are usually given on the package. Use a soft brush to apply the wash to the surface of the shelf or mold. Keep in mind that your glass will take on the texture of the shelf or mold. A very smooth coating is generally the goal.

Many coatings will be needed to fully coat the shelf with reasonable drying times between coats. It is possible to hasten the drying process by loading the shelf or mold into the kiln and taking the temperature up to 400 to 500°F. Be sure that the shelf or mold is completely dry before using.

While it's possible that the kiln wash will remain on the shelf or mold after many firings it's always a good idea to inspect for wear and re-coat if necessary.



### Pre-Fire

Evenheat suggests that you perform a test fire with your new kiln before putting it into service.

A pre fire gives you an opportunity to become familiar with the features and functions of the kiln before committing to an actual firing. It also allows your heating elements to form a protective oxide barrier. A light lubricant was used in the production of your heating elements. The pre fire will burn this off, almost immediately! You may notice a light smoke as this occurs. It's normal.

A separate control manual is included on the manuals disc included with your kiln. Refer to these manual(s) for controls programming instructions.



*Scan this QR code to view instructional programming videos for both the Evenheat Set-Pro and Rampmaster controls.*

*You will also find these instructional videos and manuals on our web site [www.evenheat-kiln.com](http://www.evenheat-kiln.com)*

Program the control to reach 1200°F as fast as possible and hold for 15 minutes (see the included controls programming manual for instruction). Once the kiln reaches 1200°F it will begin to hold for 15 minutes. As it's holding you will notice audible clicks. These clicks are made by the control relays turning the heating elements on and off and it's a normal and welcome sound.

We would encourage you to repeat this pre fire procedure if you've never fired a kiln of this design before. You won't hurt anything. Kilns are wonderful machines and they're even more wonderful when you know what to expect and how to work them.

### **Positioning of the Shelf and Glass**

Always use a shelf when firing, even when firing with a mold. If problems arise it is much easier and cheaper to replace a shelf than a kiln bottom.

Posts are used to bring the shelf up from the floor of the kiln. This allows the work to be moved closer to the lid elements while allowing heat to reach the underside of the shelf. A post length of 2" to 3" is typical. Use enough posts to support the shelf securely, 4 being the minimum.

Set the shelf on the posts positioning equally from all sides of the chamber. Set the mold on the shelf if one is being used. Position the glass on the shelf or mold as desired. You may find that using an adhesive to keep the glass in place helps. This is available from your supplier. Once the glass is positioned you're ready to fire.

### **Firing Procedure**

#### **General Firing Procedure**

It's not possible to layout an exact firing schedule for all glass. Much depends on the type of hot glass work that is being done, the type of glass that's being used and the effects desired. The following procedure is a very basic fusing schedule. It's designed primarily to teach you about the various control functions and what is done throughout a firing.

Generally speaking, glass can be taken to 1000°F in the first hour of firing. This rate allows the temperature of the glass to increase relatively quickly without breakage. After the 1000°F temperature has been reached the glass can be fired as fast as possible to the fusing temperatures or until desired results are achieved. Fusing temperatures range from 1300 to 1500°F. Once desired results are achieved the kiln is vented quickly to stop further changes to the glass. After this venting period the kiln is closed and allowed to cool slowly which anneals the glass.

#### **Firing Procedure for Automatic Controls**

Once glass is loaded prop the lid open ½ to 1" with a post or firebrick and open the peephole. This allows fumes from adhesives and organic materials to escape. Gold, silver, decals, paints release fumes while firing and will leave an unwanted finish on the glass. If you're not firing any items such as these you may skip this step.

Program your automatic control with the firing information. A separate programming manual has been included for your control. Read it thoroughly and become familiar with it before attempting to fire. It's wise to develop your firing plans before attempting to program.

Start the firing.

If the lid was propped open, close the lid once 1000°F has been reached.

Check the firing periodically. Continue to fire until desired results are achieved.

Once the desired results are achieved vent the kiln to stop further changes to the glass. Check the automatic control to see that it is either off or following your actions. It may be necessary to reprogram or skip ahead in the program to reach this point. Venting can be accomplished in many ways. You may prop the lid open with a post or firebrick or you may open and close the lid slightly for a number of times. The point here is to stop further changes to the glass. Choose a technique you feel comfortable with. It must be mentioned that protective clothing, gloves and eyewear be worn when handling a hot kiln. This is important at any stage of the firing.

Continue venting until the temperature falls to about 1100°F or so. When the chamber reaches this temperature, close the lid completely. The temperature of the firing chamber tends to rise a bit once the lid is closed. This is normal and will generally not harm or change the glass.

The glass must now be allowed to anneal. Annealing is the process of reducing internal stresses in the glass. Your glass will have an annealing temperature, however, it's often unknown and often not given by the manufacturer. In this case we perform what we call a "shotgun anneal": allowing the temperature of the kiln to cool slowly over a period of time. In this way it's assumed that the anneal temperature will be within the slow cooling range. Typically, this slow cooling takes place between 1100°F and 600°F. How slow is slow? Thinner glass anneals faster than thicker glass. General rates may be between 60 to 100°F per hour. When in doubt, go slow. You can't over anneal glass.

Once the temperature of the kiln is below your annealing range allow the kiln to cool to room temperature. Once cooled to room temperature it's safe to remove the glass from the kiln.

### **Firing procedure Using Infinite Controls (Manual Control)**

Once glass is loaded prop the lid open ½ to 1" with a post or firebrick and open the peephole. This allows fumes from adhesives and organic materials to escape. Gold, silver, decals, paints release fumes while firing and will leave an unwanted finish on the glass. If you're not firing any items such as these you may skip this step.

The goal is to reach 1000°F in about an hour. A pyrometer is a valuable tool which displays kiln chamber temperature. You'll need one. Talk to your supplier. In general, 1000° is "red heat". That is to say that once the chamber attains a nice red glow you're about at 1000°F.

Rotate all switches to the Low position and allow the kiln to fire for 30 minutes.

Rotate all switches to the Med setting and allow to fire until the temperature reaches 1000°F. These settings and times are general and you'll want to adjust them to fit your kiln, load and type of work.

Once the 1000°F has been reached, close the lid completely (if propped open) and shut all peepholes.

Rotate all switches to the High position. Check the firing periodically. Continue to fire at this high setting until desired results are achieved.

Once the desired results are achieved rotate all switches to the Off position and vent the kiln to stop further changes to the glass. Venting can be accomplished in many ways. You may prop the lid open with a post or firebrick or you may open and close the lid slightly for a number of times. The point here is to stop further changes to the glass. Choose a technique you feel comfortable with. It must be mentioned that protective clothing, gloves and eyewear be worn when handling a hot kiln. This is important at any stage of the firing.

Continue venting until the temperature falls to about 1100°F or so. When the chamber reaches this temperature, close the lid completely. The temperature of the firing chamber tends to rise a bit once the lid is closed. This is normal and will generally not harm or change the glass.

The glass must now be allowed to anneal. Annealing is the process of reducing internal stresses in the glass. Your glass will have an annealing temperature, however, it's often unknown and often not given by the manufacturer. In this case we perform what we call a "shotgun anneal": allowing the temperature of the kiln to cool slowly over a period of time. In this way it's assumed that the anneal temperature will be within the slow cooling range. Typically, this slow cooling takes place between 1100°F and 600°F. How slow is slow? Thinner glass anneals faster than thicker glass. General rates may be between 60 to 100°F per hour. When in doubt, go slow. You can't over anneal glass.

Once the temperature of the kiln is below your annealing range, turn off any remaining switches and allow the kiln to cool to room temperature. Once cooled to room temperature it's safe to remove the glass from the kiln.

### **Record Keeping**

It's recommended that you keep records of your firings. You will want to record what is being fired, when it's fired, glasses used, heating and cooling times and temperatures, switch or controller settings, venting and final results.

As mentioned in the Firing Procedure for Automatic Controls it is wise to develop your firing information on paper before actually programming the kiln. Segments, rates temperatures and the like can be reviewed before being programmed. Not only will this act as a double check, it will provide you with a written record. Accurate record keeping will allow you to repeat particular firings along with giving you a "feel" for what's going on and how it happens.

### **Kiln Maintenance**

#### **Before Each Firing**

Check the firing chamber for debris

Vacuuming your kiln before each firing will help insure that dust will not affect your ware. Look over the lid and remove any loose brick pieces.

Check all firing surfaces for cracks and kiln wash. Recoat with kiln wash if necessary.

**Lid Maintenance and Repair**

During the firing your lid will expand and contract. It's necessary to tighten the band clamps on the lid after each of the first three firings. These clamps should be checked periodically after and tightened as needed.

Small, hairline cracks may appear in the lid and bottom. This is normal and does not affect the firing in any way. Should chips or large cracks appear they should be repaired to prevent sifting or becoming larger. Small chips may be cemented back into place. For large chips, a portion of firebrick may need to be removed and a new brick, cut to size, cemented in. Sand smooth.

**Figure 1** - Chip in lid to be repaired.

**Figure 2** - Gouge with a screwdriver tip or similar object a rectangle or square outline of chipped area.

**Figure 3** - Using a screwdriver as a chisel point, gouge out chipped area.

**Figure 4** - Cut filler piece of brick to fit gouged out area. Fill gouged area with kiln repair cement.

**Figure 5** - Place filler brick into cemented area.

**Figure 6** - Use a sanding block to smooth and match rest of surface.



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6

## Side Element Replacement



As with any repair, remove power from the kiln.

**Figures 1 & 2** - Remove the red panel that houses the element ends. You will see the element ends protruding from the brick. Locate the two element ends of the faulty element and remove the connectors and black and/or blue wires from each.

**Figure 3** - Using long nose pliers, carefully remove the element from the firebrick groove. Go easy, the brick is fragile and will break if care is not given.

**Figures 4 & 5** - Install the new element. Start by inserting one end through the brick and attach the connector and black or blue wire. Using a wooden spoon or similar device, push the element into the groove. Keep in mind that the element is longer than the groove. This design allows the element to expand and contract without pulling out of the groove. Go slow and you'll do just fine.

**Figures 6 & 7** - Insert the other end of the element through the brick and attach the element connector and black or blue wire. Use wire cutters to snip off excess element ends.

Re-attach the red panel to the kiln.



Figure 1



Figure 2




Figure 3



Figure 4



Figure 5



Figure 6



Figure 7

## Lid Element Replacement



As with any repair, remove power from the kiln.

**Figures 1 & 2** - Remove the red panel located on the lid. This panel houses the lid element ends. You will see the element ends protruding from the brick. Locate the two element ends of the faulty element and remove the brass connectors and the black and/or blue wires from each. Make a note of which wire connects to which element end. *The brass connectors are secured tightly. It's recommended that you grasp the brass connector with pliers while performing this procedure.*

**Figure 3** - Using long nose pliers remove the element from the lid groove. Go easy, the brick is fragile and will break if care is not given.

**Figures 4, 5, 6, & 7** - Install the new element. Start by inserting one end through the brick. Pull the element end until snug and place cylindrical porcelain insulator on. Install the brass connector and fully insert wire. Tighten the brass connector set screw. Be sure that the set screw is tight – this ensures a good connection. Use wire cutters to snip off excess element ends.

Using a wooden spoon or similar device, push the secured end of the element into the lid groove. Be careful not to destroy the groove edges. Continue inserting the element until you're about 3/4 of the way complete.

**Figures 8 & 9** - Install the remaining end of the element through the brick as described in step 3. Once completed, finish inserting the element in the lid groove. *It's possible that the new element may be slightly longer or shorter than the lid groove. The element is quite pliable and you may physically stretch or compress it to fit.*

Double check that you have cut off all excess element leads at the brass connectors.

Re-install the red control panel back on the lid. When doing so, move wiring away from the brass connectors as it's placed on.



Figure 1




Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Figure 7



Figure 8




Figure 9

### Thermocouple Replacement



As with any repair, remove power from the kiln.

**Figure 1** - Remove the red panel. Locate the oval shaped porcelain thermocouple block and remove the outside mounting screws.

**Figure 2** - Pull thermocouple out.

**Figure 3** - Locate the center 2 screws that hold the thermocouple wires in place and loosen them. Remove thermocouple wires from block. Attach thermocouple wires to new thermocouple & block. Tighten all screws securely. Replace the red panel making sure to keep all black wires away from the white thermocouple lead.

*Note: if after the thermocouple has been replaced, you find the temperature now reads down, you need to be sure that the magnetic lead (which is marked in red) is connected to the magnetic side (red) of the thermocouple wire.*



Figure 1



Figure 2



Figure 3

### Sidewall Maintenance and Repair



Always remove power from the kiln before attempting any repairs. If glass or other foreign material has embedded itself into the brick use a small screwdriver or knife to remove. Be careful, the firebrick is fragile. Foreign matter on the brick will lead to further destruction and possible element failure. Should a piece of brick chip off from the sidewall, it's possible to cement it back on. Care should be used around heating elements. Do not allow the cement to get on the heating elements as this may cause element failure.

**Trouble Shooting**

All Kilns are tested and checked at the factory before being cleared for shipment. Most problems with newly installed kilns are in the customers' service to the kiln. Even if installed by an electrician the main problems are: wire size, circuit breaker or fuse size being too small, loose connections, etc.



When working on repairs, be sure power supply cord is removed from wall receptacle and all power is turned off. A qualified electrician or service person should do all repairs and follow all local, state and federal codes.



The electrical supply going into a kiln can be dangerous if not done properly. IMPORTANT – Check electrical specifications.

TROUBLE	PROBABLE CAUSE	CORRECTIONS
Controller Program Running and Kiln doesn't heat or Switches on and Kiln doesn't heat.	(a) Blown fuse/tripped circuit breaker (b) Kiln NOT plugged in (c) Loose connection (d) Faulty switch (e) Element burned out (f) Stuck relay (g) Improper data programmed	(a) Replace fuse/reset circuit breaker (b) Plug kiln in (c) Tighten (d) Replace (e) Replace (f) Replace (g) Review and re-enter data
Fuse blows/circuit breaker trips as soon as kiln is turned on.	(a) Short in Kiln (b) Service wired wrong (c) Fuse or circuit breaker too small (d) Overloaded circuit	(a) Check wiring (b) Have electrician check service from fuse box to kiln (c) Check electrical specifications – replace with right size (see note at bottom) (d) Disconnect all other appliances, etc. from circuit
Fuse blows/circuit breaker trips during firing.	(a) Defective fuse(s) or worn circuit breaker (b) Fuse, wire size or circuit breaker too small (c) Overloaded circuit (d) Loose or corroded connections (e) Short in kiln	(a) Replace fuse(s) or breaker (b) Check electrical specifications – replace with right size (see note at bottom) (c) Disconnect all other appliances, etc. from circuit (d) Tighten or clean (e) Check wiring
Kiln takes too long to fire.	(a) Voltage too low (b) Service wired wrong (c) Loose connection between fuse box and kiln wiring (d) Element or switch burned out (e) Elements gradually wearing out (f) Relay stuck (g) One side of fuses or breaker blown (h) Improper data programmed	(a) Have electrician or power company check voltage – see specifications (b) Have electrician check service – see specifications (c) Check and tighten all connections (d) Replace (e) Replace (f) Replace (g) Replace (h) Review and re-enter data
Kiln heats with Computer Controller off.	(a) Relay Stuck	(a) Replace
Kiln shuts off too soon.	(a) Fuse blows/circuit breaker trips (b) Computer controller displays Error Message	(a) Replace fuse/reset circuit breaker (b) See Computer Controller Operating Handbook
Hot or partially melted plug or wall receptacle * Kiln should be shut down immediately – DISCONNECT POWER.	(a) Loose connection at wall receptacle (b) Worn receptacle or plug (c) Defective cord (d) Corroded cord prongs/or receptacle terminals	(a) Have electrician check and tighten connections (b) Have electrician replace (c) Replace immediately (d) Sand cord prongs to remove corrosion. A qualified electrician can replace cord or receptacle if needed.

---

**EVENHEAT KILN, INC.**  
**LIMITED KILN WARRANTY**

Evenheat Kiln, Inc. guarantees to the original purchaser that for a period of two full years (1 year for Superwool lids) from the date of purchase the kiln will be free of defects in workmanship and materials when used under normal and proper operating conditions. Evenheat will replace or repair any defective part as specified..

**FOR THE WARRANTY TO BE EFFECTIVE THE PURCHASE MUST:**

- (1) Provide written proof of date of purchase. (Warranty card sent in at time of purchase.)
- (2) Notify the Evenheat Distributor/Dealer from whom the kiln was purchased, within 10 days after defect has been discovered.
- (3) Make kiln immediately available for inspection.

**FOR WARRANTY REPAIRS:**

- (1) Warranty repairs should be handled through the Distributor/Dealer from whom the kiln was purchased, who will arrange for any repairs or replacement of parts under the terms of this warranty upon receipt of the kiln (or defective part). Otherwise the defective part may be returned (postage prepaid) to Evenheat Kiln, Inc. P.O. Box 399, 6949 Legion Drive Caseville, MI 48725. If, after factory examination, the original part is found to be defective, a new or repaired part will be shipped prepaid by Evenheat Kiln, Inc.
- (2) If the entire kiln is to be returned to the factory, all transportation costs will be borne but he purchaser. The purchaser should notify Evenheat Kiln, Inc. (989) 856-2281 prior to shipping. Evenheat will help advise the best shipping method and if it is necessary to return the entire kiln or only certain parts. Warranty work will be performed within 30 days after defective part is returned to the factory.
- (3) Evenheat Kiln, Inc. reserves the right, at its option, to replace the entire kiln or any part of it in order to fulfill its obligation under this warranty.

**THIS WARRANTY DOES NOT COVER:**

- (1) Freight damage, kilns altered in any way, abuse or neglect, moisture, improper storage or installation.
- (2) Kiln overfired (reaching temperature higher than melting point of ware inside kiln) regardless of cause.
- (3) Dawson Kiln Sitter or Limit Timer.
- (4) Kilns operated on incorrect voltage.
- (5) Improper electrical installation.
- (6) Kiln furniture or ware.
- (7) Kilns used for reduction or salt firing.
- (8) Kilns used for purposes other than the firing of glass materials.
- (9) Kilns operated in excess of the cone or temperature on the rating plate.
- (10) Damage to Property or personal injury that may occur from kilns that are fired on or near wood floors or combustibles.
- (11) Damage to property or personal injury that may occur from improper ventilation of the work area and building structure.

This warranty is in lieu of all other warranties, expressed, or implied.

Evenheat Kiln, Inc. neither assumes nor authorizes any Distributor/Dealer, Retailer or employee to assume for it any other obligations or liabilities in connection with Evenheat Kilns.

This warranty is limited as specified above and excludes incidental or consequential damages. Some states or providences do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

The glass kiln manual included with your kiln includes kiln stand assembly instructions for many models. However, if you have purchased model GTS 23 please use the updated assembly instructions shown below.

GTS 23 Stand Parts Include:

- 4 27" Stand Cross Sections with 4 bolt holes
- 2 27" Stand Cross Sections with 8 bolt holes
- 4 Standard Legs
- 2 Dyna-Lift Ready Legs (Identified as the legs with square holes)
- 2 Stand Trusses
- 2 "L" Brackets
- 38 Nuts and Bolts
- 6 Plastic Stand Feet

Tools Needed:

- Large Phillips Screwdriver
- 7/16" Wrench

Step 1:

Place all frame angles as shown below. Note that the frame angles with 8 holes are placed opposite of each other.



Step 2:

Place all stand legs as shown below. Please note that the 2 Dyna-Lift Ready legs are placed, on one side, at the center positions. See image for guidance. Position these 2 legs so the single square hole is to the inside of the frame. You will be connecting a truss to this point. Position the 2 "L" Brackets on one side at the center positions.



Step 3:

Once all stand legs are positioned, bolt the legs to the stand. Finger tighten at this point.



Step 4:

Install the trusses as shown below. Finger tighten and place plastic feet on each leg.



Step 5:

Turn the stand over and tighten all bolts.

You will have 4 nuts and bolts left over. Don't throw these away. These nuts and bolts are provided for attaching the Dyna-Lift lid lift assist. If you are not installing the Dyna-Lift we suggest that you insert these extra nuts and bolts to the 2 Dyna-Lift Ready legs. You will find 4 empty square holes in these Dyna-Lift ready legs. Place them here and tighten. If and when you install the Dyna-Lift this hardware will be there.



**Front**

Step 6:

If you have purchased a Dyna-Lift this is the point where you'll attach it to the kiln stand. Please refer to the Dyna-Lift instructions for specific steps.

If you have not purchased a Dyna-Lift for your new GTS 23 you may want to consider it. The Dyna-Lift lightens the force needed to operate the kiln lid. It does so with ease and grace and with no negative effects upon the kiln itself. Hallmarks of the design include no kiln body connection, single point lifting and emphasis on allowing the lid to act naturally.

Step 7:

Position your stand where you want to place the kiln and place your kiln on the stand. Keep in mind to place your kiln on a non-combustible surface and at least 16' from any walls. Your kiln manual provides more information about kiln placement. Please read and follow these requirements.

The glass kiln manual included with your kiln includes kiln stand assembly instructions for many models. However, if you have purchased model GTS 2541 please use the updated assembly instructions shown below.

GTS 2541 Stand Parts Include:

- 4 30.5" Stand Cross Sections
- 2 36.5" Stand Cross Sections
- 6 Standard 8" Legs
- 2 Dyna-Lift Ready 8" Legs (Identified as the legs with square holes)
- 2 Stand Trusses
- 38 Nuts and Bolts
- 8 Plastic Stand Feet

Tools Needed:

- Large Phillips Screwdriver
- 7/16" Wrench


Step 1:

Place all cross sections as shown below.



Step 2:

Place all stand legs as shown below. Please note that the 2 Dyna-Lift Ready legs are placed, on one side, at the center positions of the long, 36.5" stand sections. See image for guidance. Position these 2 legs so the single square hole is to the inside of the frame. You will be connecting a truss to this point.



Step 3:

Once all stand legs are positioned, bolt the legs to the stand. Finger tighten at this point.



Step 4:

Install the trusses as shown below. Finger tighten and place plastic feet on each leg.



Step 5:

Turn the stand over and tighten all bolts.

You will have 4 nuts and bolts left over. Don't throw these away. These nuts and bolts are provided for attaching the Dyna-Lift lid lift assist. If you are not installing the Dyna-Lift we suggest that you insert these extra nuts and bolts to the 2 Dyna-Lift Ready legs. You will find 4 empty square holes in these Dyna-Lift ready legs. Place them here and tighten. If and when you install the Dyna-Lift this hardware will be there.



**Front**

Step 6:

If you have purchased a Dyna-Lift this is the point where you'll attach it to the kiln stand. Please refer to the Dyna-Lift instructions for specific steps.

If you have not purchased a Dyna-Lift for your new GTS 2541 you may want to consider it. The Dyna-Lift lightens the force needed to operate the kiln lid. It does so with ease and grace and with no negative effects upon the kiln itself. Hallmarks of the design include no kiln body connection, single point lifting and emphasis on allowing the lid to act naturally.

Step 7:

Position your stand where you want to place the kiln and place your kiln on the stand. Keep in mind to place your kiln on a non-combustible surface and at least 16" from any walls. Your kiln manual provides more information about kiln placement. Please read and follow these requirements.



# Dyna-Lift Installation Instructions For Dyna-Lift Ready GTS 2541 Kilns

For Dyna-Lift Ready Evenheat GTS 2541 Kilns  
Serial Numbers 95422 and Higher

## *Dyna-Lift*

Patent Pending

Thank you for purchasing the Dyna-Lift lid lift assist for your Evenheat kiln. We know you're going to enjoy it.

Before installing the Dyna-Lift you must first assemble the kiln stand if you have not already done so. Your "Dyna-Lift Ready" Evenheat kiln was supplied with stand assembly instructions. Please refer to those instructions for stand assembly. The final step (step 6) of the stand assembly instructions will refer you back to these instructions for installation of the Dyna-Lift. It is at this point that we will begin.

### Step 1: Preparing the Stand

Remove the 8 nuts and bolts located on the back, center legs of the stand as shown.



### Step 2: Attaching the Dyna-Lift to the Stand

Place the Dyna-Lift mounting bracket against these back center legs and install the 8 nuts and bolts. Tighten securely.



### Step 3: Lifting Spring Installation

Lift the lifting arm all the way up and install the 2 lifting springs. The lifting springs are included in the parts package. Simply place the spring ends in the grooves provided on the upper and lower mounting pins. One spring is placed on each side.



The Dyna-Lift is now attached to the stand.



### Step 4: Positioning of the Dyna-Lift Stand

Position your Dyna-Lift stand where you want to place the kiln. Keep in mind to place your kiln on a non-combustible surface and at least 16" from any walls. Your kiln manual provides more information about kiln placement. Please read and follow these requirements.

### **Step 5: Placing the Kiln on the Stand**

Place your kiln on the stand. When placing, center the kiln left to right. Also when placing the kiln, position it so the back of the kiln makes contact with the Dyna-Lift mounting bracket.



### **Step 6: Attaching the Dyna-Lift Link to the Lid Handle**

The lid handle rod on your kiln is secured with collar clamps. Using the included 1/8" allen wrench loosen the set screw on the right side collar clamp and remove it. The 1/8" allen wrench is included in the parts package.



Pull the lid rod out of the right lid bracket until its end is roughly at the mid-point of the kiln. Place 1 collar clamp onto the lid rod. Extra collar clamps are included in the parts package.



Remove the 2 lift springs that were installed previously and gently lower the Dyna-Lift lifting arm down to the lid handle area.

Insert the lid handle rod into the hole in the link. Once inserted, place 1 collar clamp on the lid handle rod. Extra collar clamps are included in the parts package.



Re-insert the lid handle rod into the right side lid bracket. Place the collar clamp on the end of the lid handle rod and tighten with the allen wrench.



Center the Dyna-Lift link on the lid handle rod. Once centered move the collar clamps up to each side of the link and tighten with the 1/8" allen wrench.



### Step 7: Re-install the Dyna-Lift Springs

This is a 2 person job.

Have one person lift the lid to the open position. While the lid is being held up re-install the 2 lifting springs as per Step 3.

Once the springs are installed, check the operation of the Dyna-Lift. The Dyna-Lift is now connected to the kiln and lifting force has been decreased to a very manageable level.

### Step 8: Installing the Security Lid Bar

Place the notch of the included security lid bar into the wireformed catch located on the left side of the kiln. The notch should be facing the rear of the kiln. The security lid bar is included in the parts package.



Remove the nut and bushing from the pin mount. Place the upper hole of the lid security bar on the pin mount located on the lid. Install the bushing on the pin and tighten. Install the bushing so it sinks into the hole on the security lid bar. This allows the bar to move against the bushing and not the pin threads.



Install the nut on the pin and tighten.



The security lid bar is now installed.



**Step 10: Installing the Lid Vent (optional)**

Place the lid vent bracket onto the end of the left side lid handle rod. The lid vent bracket is included in the parts package. The teeth should be pointing towards the kiln. Insert 1 collar clamp onto the lid handle rod next to the lid vent bracket and tighten. Extra collar clamps are included in the parts package. You will want this vent bracket to swing freely. Adjust the collar clamp as needed to achieve this.



Your New  
*Dyna-Lift*  
is Now Installed. Enjoy!

